安全使用说明书
尺寸:28*55mm
材质:80g书纸,双面4C印刷,风琴折

正面

UPENDS
SWITCH MAX
Device

User Manual

Please read this leaflet carefully before using this product. Keep this leaflet as it contains important information that you may need again. This product is not intended for use by children or non-smokers.

WARNING
Keep out of reach of children and animals.
This product contains nicotine which is a highly addictive substance.
This product may be hazardous to health. Not recommended for young people and non-smokers.
Call a poison center or doctor/ physician if you feel unwell.



Danger

THIS PRODUCT IS NOT SUITABLE FOR USE BY
-Persons under the age of 18.
-Pregnant or breast-feeding women.
-Persons with an unstable heart condition, severe hypertension or diabetes.

IMPORTANT SAFETY INFORMATION
Stop using this product immediately and seek medical advice if you experience any of the following conditions:
Development of an irregular heartbeat;
Allergic reaction such as rash, itching or swelling of the tongue, mouth or throat;
Feeling faint, nausea, headache or any other unusual or adverse effect.
This product is not intended for use by persons with reduced sensory, physical, or mental capabilities, or lack of experience and knowledge unless they have been given supervision or instruction concerning the use of the product by a person responsible for their safety.

INSTRUCTIONS FOR THE USE AND STORAGE OF THE PRODUCT
Always make sure the device is not damaged or leaking before using it. Store the product with e-liquid in a dark and dry place. Store the product at a temperature between 10-30°C and out of direct sunlight.
Do not refrigerate, freeze, heat or store the product at a temperature above 30°C.
Always keep the device between 0°C and 25°C for optimal performance. Exposure to extreme temperatures may reduce the capacity and duration of the battery.
Avoid exposing the device to a temperature above 35°C as this may cause permanent damage.

Suitable Temperature & Humidity	
Charging	0°C ~ +45°C
Usage	-10°C ~ +60°C
Humidity	10% ~ 90%

The device must be stored and used in a dry environment. It must not be exposed to rain, high humidity or any kind of liquid that could damage the electronic circuits. Dispose of the packaging and its contents in accordance with national and local regulations.

POSSIBLE ADVERSE EFFECTS
First-time e-cigarette users may experience irritation of the mouth, a dry throat or cough. If the symptoms persist for more than 48 hours or become severe, visit a general practitioner and report the incident details.

ADDICTIVENESS
This product does not contain nicotine. No other ingredient is known to be addictive.

TOXICITY
This product may produce toxic effects if consumed orally, especially in infants or children. If swallowed, visit your general practitioner with this leaflet immediately.

CONTRA-INDICATIONS
The consumption of this product is not recommended for people suffering from heart disease, high blood pressure, diabetes, liver or kidney problems, long-term throat disease or those taking medication for asthma.

INDICATIONS FOR USE



Remove the sealing sticker



Connect the pod to the battery device



Enjoy the vaping

背面

Note:
· UPENDS SWITCH MAX device is supplied without pods. The prefilled pod is sold separately.
· The device is only compatible with the UPENDS SWITCH MAX Prefilled Pod. Do not use it until the pod is connected. Do not use with other pods other than UPENDS SWITCH MAX Prefilled Pod.
· Please replace the pod before the e-liquid runs out to avoid dry hits.
· This device is a closed system, therefore please do not open, tamper with, or attempt to open or recharge this device. Do not break or crush the device.

TROUBLESHOOTING
Device will not turn on
Charge the device using the type-C cable. If the device still does not turn on, contact Customer Service.

Device does not release smoke
Check for any liquid leaks or dust on contact pins and clean them thoroughly. If there is still no smoke, contact Customer Service.

E-liquid leaking from the pod
The pod is used up and needs to be replaced.

Device will not charge
Try charging with a different charger and type C cable. If the device still does not charge, contact Customer Service.

For all other types of faults, please contact customer service through the seller or our official website www.upends.com. Do not, under any circumstances, make any modifications to the device as this will void the warranty

DISPOSAL AND RECYCLING
This product contains a non-replaceable lithium-ion polymer battery. Electrical equipment and batteries should not be disposed of as regular household waste but should be collected separately for recovery and recycling. We are committed to minimizing our impact on the environment.

DESIGNED BY UPENDS
Manufactured By ALD GROUP LIMITED
Address: ALD Building, No.2 Industrial 3rd Road, Shixin Community, Shiyan Town, Bao' an District, Shenzhen, 518107, China
Tel: +86-755-2668-7707
Web: www.upends.com
Email: info@upends.com

